




100% of Actual Size
Screen Print

POSITION A




100% of Actual Size
Pad Print

POSITION D




POSITION E




Please note when pen is printed in position D,
print is not visible when in the notebook holder.

100% of Actual Size
Direct Digital

POSITION D




POSITION E




Please note when pen is printed in position D,
print is not visible when in the notebook holder.


100% of Actual Size
Pad Print





100% of Actual Size
Pad Print



100% of Actual Size
Screen Print (one colour)



100% of Actual Size
BACK Pad Print



100% of Actual Size
BACK Screen Print (one colour)

